




Print to scale
1"



extra copies



Fold and bend as shown in the drawings.



A diagram of a spring scale. The scale has a vertical rod with a hook at the top. A weight hanger is attached to the hook, and a weight is attached to the hanger. The scale is marked with a central zero point and two 5-inch marks on either side.



conical
spring
(glued to rotor)

